


RADIATOR FAN AND CONDENSER FAN



SYSTEM OUTLINE

Fan motor operation

The fan motor is operated according to the condition of the A/C operation, water temperature, or abnormality in the A/C system.

SERVICE HINTS

A3 A/C SINGLE PRESSURE SW

3-2 : Open above approx. **15.5 kgf/cm² (220 psi, 1520 kpa)**

Close below approx. **12.5 kgf/cm² (178 psi, 1226 kpa)**

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A1	32 (1ZZ-FE)	A3	34 (2ZZ-GE)	R1	33 (1ZZ-FE)
	34 (2ZZ-GE)	E3	32 (1ZZ-FE)		35 (2ZZ-GE)
A3	32 (1ZZ-FE)		34 (2ZZ-GE)		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Instrument Panel Brace RH)
2F	23	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2G		
2H		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IE5	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Brace LH)
IG2	46	Engine Room No.2 Wire and Instrument Panel Wire (Right Kick Panel)

: GROUND POINTS

Code	See Page	Ground Points Location
EA	40 (1ZZ-FE)	Front Right Fender
	42 (2ZZ-GE)	
EB	40 (1ZZ-FE)	Front Left Fender
	42 (2ZZ-GE)	
EM	40 (1ZZ-FE)	
	42 (2ZZ-GE)	
IG	44	Cowl Side Panel RH