


CHARGING



SERVICE HINTS

G2 (B) GENERATOR

- (B) 3-GROUND : **13.9–15.1** volts with the engine running at **2000** rpm and **25°C (77°F)**
13.5–14.3 volts with the engine running at **5000** rpm and **115°C (239°F)**
 (B) 1-GROUND : **0–4** volts with the ignition SW at **ON** position and the engine not running

○ : PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
C12	A	36	E3	B	32 (1ZZ-FE)	G1	A	32 (1ZZ-FE)
C13	B	36			34 (2ZZ-GE)			34 (2ZZ-GE)
E2	A	32 (1ZZ-FE)	E4	C	32 (1ZZ-FE)	G2	B	32 (1ZZ-FE)
		34 (2ZZ-GE)			34 (2ZZ-GE)			34 (2ZZ-GE)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IB	25	Engine Room Main Wire and Instrument Panel J/B (Instrument Panel Brace RH)
II	25	Instrument Panel Wire and Instrument Panel J/B (Instrument Panel Brace RH)
IM		
2A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
2C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	40 (1ZZ-FE)	Engine Wire and Engine Room Main Wire (Inside of Engine Room R/B No.1)
	42 (2ZZ-GE)	
IE4	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Brace LH)
IE5		

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IF	44	Instrument Panel Brace RH