


SERVICE HINTS

G2 (B) GENERATOR

- (B) 3-GROUND : **13.9- 15.1** volts with the engine running at **2000** rpm and **25°C (77°F)**
13.5- 14.3 volts with the engine running at **5000** rpm and **115°C (239°F)**
 (B) 1-GROUND : **0- 4** volts with the ignition SW at **ON** position and the engine not running

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C11	38	F4	36	I11	A 39
D3	A 38	G1	A 36	J9	A 39
	B 38	G2	B 36	J10	B 39

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
6	31	Engine Room R/B No.6 (Radiator Support RH)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IJ	22	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
2B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2C	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
3D		

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	42	Engine Room Main Wire			