

L PART NUMBER OF CONNECTORS

| Code | Part Name | Part Number | Code | Part Name | Part Number |
|------|--|-------------|------|---|-------------|
| A 1 | A/C Condenser Fan Motor | 90980-10928 | C19 | Cruise Control ECU | 90980-11391 |
| A 2 | A/C Magnetic Clutch and Lock Sensor | 90980-10942 | C20 | Camshaft Timing Oil Control Valve | 90980-11162 |
| A 3 | A/C Triple Pressure SW (A/C Dual and Single Pressure SW) | 90980-10943 | D 1 | Data Link Connector 1 | 90980-11195 |
| A 4 | ABS Actuator and ECU | 90980-11851 | D 2 | Data Link Connector 3 | 90980-11665 |
| A 5 | ABS Speed Sensor Front LH | 90980-11075 | D 3 | Daytime Running Light Relay (Main) (Canada) | 90980-10807 |
| A 6 | ABS Speed Sensor Front RH | | | Daytime Running Light Relay (Main) (Except Canada) | 90980-11058 |
| A 7 | Airbag Sensor Front LH | 90980-11856 | D 4 | Diode (Daytime Running Light) | 90980-10962 |
| A 8 | Airbag Sensor Front RH | | D 6 | Door Courtesy SW Front LH | 90980-10871 |
| A 9 | Ambient Temp. Sensor | 90980-11030 | D 7 | Door Courtesy SW Front RH | |
| A10 | A/C Amplifier | 90980-10803 | D 8 | Door Courtesy SW Rear LH | |
| A11 | A/C Evaporator Temp. Sensor | 90980-10795 | D 9 | Door Courtesy SW Rear RH | 90980-10908 |
| A12 | A/C SW | 90980-11280 | D10 | Door Key Lock and Unlock SW LH | |
| A13 | Airbag Squib (Front Passenger Airbag Assembly) | 90980-11886 | D11 | Door Key Lock and Unlock SW RH | |
| A14 | Airbag Squib (Steering Wheel Pad) | 90980-10850 | D12 | Door Lock Control SW LH | 90980-11471 |
| A15 | Ashtray Illumination | 81945-33010 | D13 | Door Lock Control SW RH (w/o Power Window) | |
| A16 | Automatic Light Control Sensor | 90980-11107 | | Door Lock Control SW RH (w/ Power Window) | 90980-10601 |
| A17 | ABS Speed Sensor Rear LH | 90980-10859 | D14 | Door Lock Motor and Unlock Detection SW Front LH | 90980-11150 |
| A18 | ABS Speed Sensor Rear RH | 90980-11060 | D15 | Door Lock Motor or Unlock Detection SW Front RH | |
| A20 | Air Inlet Control Servo Motor | 90980-11909 | D16 | Door Lock Motor or Unlock Detection SW Rear LH | |
| B 1 | Back-Up Light SW | 90980-11250 | D17 | Door Lock Motor or Unlock Detection SW Rear RH | |
| B 2 | Brake Fluid Level Warning SW | 90980-11207 | D18 | Door Lock Motor Rear LH | 90980-11019 |
| B 3 | Blower Motor | 90980-10214 | D19 | Door Lock Motor Rear RH | |
| B 4 | Blower Resistor | 90980-11136 | D20 | Door Lock Motor, Unlock Detection SW and Door Key Lock and Unlock SW Front LH | 90980-11858 |
| B 5 | Blower SW | 90980-10877 | D21 | Door Lock Motor and Door Key Lock and Unlock SW Front RH | |
| B 6 | Back-Up Light LH | 90980-10860 | D22 | Diode (Fog Light) | 90980-10962 |
| B 7 | Back-Up Light RH | | D23 | Diode (Buckle SW) | 90980-11398 |
| B 8 | Buckle SW | 90980-10825 | E 1 | Electronically Controlled Transmission Solenoid | 90980-11143 |
| C 1 | Camshaft Position Sensor | 90980-10947 | E 2 | Engine Coolant Temp. Sensor and Water Temp. Sender | 90980-11451 |
| C 2 | Crankshaft Position Sensor | | E 4 | Engine Control Module | 90980-11390 |
| C 3 | Cruise Control Actuator | 90980-11150 | E 5 | Engine Control Module | 90980-11391 |
| C 4 | Center Airbag Sensor Assembly | 90980-11869 | E 6 | Engine Control Module | 90980-11392 |
| C 5 | Center Airbag Sensor Assembly | 90980-11868 | E 7 | Engine Control Module | 90980-11421 |
| C 6 | Center Airbag Sensor Assembly | 90980-11867 | E 8 | Engine Control Module | 90980-11476 |
| C 7 | Cigarette Lighter | 90980-10760 | E 9 | Engine Control Module | 90980-11637 |
| C 8 | Cigarette Lighter Illumination | 90980-11148 | E10 | Engine Control Module | 90980-11638 |
| C 9 | Clock | 90980-11013 | F 1 | Front Turn Signal and Parking Light LH | 90980-11020 |
| C10 | Clutch Start SW | 90980-10825 | F 2 | Front Turn Signal and Parking Light RH | |
| C11 | Combination Meter | 90980-11115 | F 3 | Front Wiper Motor | 90980-11194 |
| C12 | Combination Meter | 90980-11113 | | | |
| C13 | Combination Meter | 90980-11114 | | | |
| C14 | Combination Meter | 90980-11116 | | | |
| C15 | Combination SW | 90980-11672 | | | |
| C16 | Combination SW | 90980-11616 | | | |
| C17 | Combination SW | 90980-11594 | | | |
| C18 | Cruise Control Clutch SW | 90980-10906 | | | |

Note: Not all of the above part numbers of the connector are established for the supply.

| Code | Part Name | Part Number | Code | Part Name | Part Number |
|------|--|-------------|------|---------------------------------------|-------------|
| F 4 | Fusible Link Block | 82620-02020 | J15 | Junction Connector | 90980-11398 |
| F 5 | Front Door Speaker LH | 90980-10825 | J16 | Junction Connector | 90980-10803 |
| F 6 | Front Door Speaker RH | | J17 | Junction Connector | 90980-11398 |
| F 7 | Fuel Pump and Sender | 90980-11077 | J18 | Junction Connector | 90980-11238 |
| F 8 | Fog Light LH | 90980-11156 | J19 | Junction Connector | 90980-10803 |
| F 9 | Fog Light RH | 90980-11156 | J20 | Junction Connector | 90980-10803 |
| F10 | Fog Light Relay | 82660-20340 | K 1 | Knock Sensor | 90980-11166 |
| F11 | Fuse Folder | 82610-20080 | L 1 | License Plate Light | 90980-11159 |
| G 1 | Generator | 90980-09213 | L 3 | Luggage Compartment Light | 90980-11148 |
| G 2 | Generator | 90980-11349 | L 4 | Luggage Compartment Light SW | 90980-11097 |
| H 1 | Headlight LH (High) | 90980-11095 | M 2 | Moon Roof Control Relay | 90980-10803 |
| H 2 | Headlight LH (Low) | 90980-11096 | M 3 | Moon Roof Control SW | 90980-10367 |
| H 3 | Heated Oxygen Sensor (Bank 1 Sensor 1) | 90980-11028 | M 4 | Moon Roof Motor and Limit SW | 90980-11011 |
| H 4 | Horn | 90980-10619 | M 5 | Mass Air Flow Meter | 90980-11317 |
| H 5 | Hazard SW | 90980-10801 | N 1 | Noise Filter (Ignition) | 90980-10843 |
| H 6 | Heated Oxygen Sensor (Bank 1 Sensor 2) | 90980-11028 | O 1 | Oil Pressure SW | 90980-11363 |
| H 7 | High Mounted Stop Light | 90980-11148 | O 2 | O/D SW | 90980-10795 |
| H 8 | Headlight RH (High) | 90980-11095 | P 1 | Park/Neutral Position SW | 90980-11784 |
| H 9 | Headlight RH (Low) | 90980-11096 | P 2 | Power Steering Oil Pressure SW | 90980-11428 |
| I 1 | Idle Air Control Valve | 90980-11145 | P 3 | Parking Brake SW | 90980-10871 |
| I 2 | Ignition Coil and Igniter No.1 | 90980-11885 | P 4 | Power Window Control SW Front RH | 90980-10789 |
| I 3 | Ignition Coil and Igniter No.2 | | P 5 | Power Window Control SW Rear LH | |
| I 4 | Injector No.1 | 90980-11875 | P 6 | Power Window Control SW Rear RH | |
| I 5 | Injector No.2 | | P 7 | Power Window Master SW | 90980-10807 |
| I 6 | Injector No.3 | | P 8 | Power Window Motor Front LH | 90980-10860 |
| I 7 | Injector No.4 | | P 9 | Power Window Motor Front RH | |
| I10 | Ignition SW | 90980-11615 | P10 | Power Window Motor Rear LH | |
| I11 | Integration Relay | 90980-11121 | P11 | Power Window Motor Rear RH | 90980-11862 |
| I12 | Integration Relay | 90980-10807 | P12 | Pretensioner LH | |
| I13 | Interior Light | 90980-10935 | P13 | Pretensioner RH | |
| I14 | Ignition Coil and Igniter No.3 | 90980-11885 | P14 | Power Outlet | 90980-10760 |
| I15 | Ignition Coil and Igniter No.4 | | P15 | Personal Light | 90980-11794 |
| J 1 | Junction Connector | 90980-11398 | P16 | Power Outlet Relay | 82660-20340 |
| J 2 | Junction Connector | 90980-10803 | R 1 | Radiator Fan Motor | 90980-10928 |
| J 3 | Junction Connector | | R 2 | Radio and Player | 90980-10996 |
| J 4 | Junction Connector | 90980-11661 | R 3 | Radio and Player | 90980-10997 |
| J 5 | Junction Connector | | R 4 | Rear Window Defogger SW | 90980-12113 |
| J 6 | Junction Connector | 90980-11542 | R 5 | Remote Control Mirror SW | 90980-11450 |
| J 7 | Junction Connector | 90980-10803 | R 6 | Rheostat | 90980-10216 |
| J 8 | Junction Connector | 90980-10976 | R 7 | Rear Combination Light LH | 90980-10795 |
| J 9 | Junction Connector | 90980-11661 | R 8 | Rear Combination Light RH | |
| J10 | Junction Connector | | R 9 | Rear Speaker LH | 90980-11060 |
| J11 | Junction Connector | 90980-11238 | R10 | Rear Speaker RH | |
| J12 | Junction Connector | 90980-11502 | R11 | Rear Window Defogger (+) (TMMC Made) | 90980-10914 |
| J13 | Junction Connector | 90980-11542 | | Rear Window Defogger (+) (NUMMI Made) | 90980-10786 |
| J14 | Junction Connector | 90980-10830 | | | |

L PART NUMBER OF CONNECTORS

[illegible]

Note: Not all of the above part numbers of the connector are established for the supply.

